





FIFE CORPORATION
 Post Office Box 26508
 Oklahoma City, Oklahoma 73126, U.S.A.
 Phone: (405) 755-1600 Fax: (405) 755-8425
 Telex: 747276

INSTALLATION INSTRUCTIONS



SQUARE BAR SIZE	A	B MAXIMUM	C
1.0 (25)	2.0 (51)	6.0 (152)	2.94 (75)
1.25 (32)	2.5 (64)	7.56 (192)	4.5 (114)

NOTES:

1. All dimensions in () parentheses are in millimeters unless otherwise specified.
2. Corrosion resistant models are available.
3. Models are available with M12 (metric) mounting thread as well as for 25 millimeter square bar.