

MAINTENANCE GUIDE

Tidland External Element Shafts



External Element Shaft Maintenance Guide

Use the reference chart on the back page to identify the type of end block and air bladder seal used on your Tidland External Element shaft. Contact Maxcess Customer Service for ordering of replacement parts.

For any Tidland air shaft, the spare parts kit part number is the shaft part number with "SP" suffix

Example: Shaft part #: 270024901

Spare parts kit #: 270024901SP



Spare Parts kits for Tidland external element shafts will include air bladder, end blocks, and all components required

Reference the user manual for each Series for detailed instructions of how to replace air bladders

Watch Now!





END BLOCK OVERVIEW

CLICK OR SCAN TO WATCH SHORT VIDEO



HOW TO CHANGE AIR BLADDER ON EXTERNAL ELEMENT SHAFTS

CLICK OR SCAN TO WATCH SHORT VIDEO

REFERENCE CHART

Series	Photo	End Block Style	Bladder	Bladder Punch Guide	Hole Punch Tool	Non-air End Termination	User Manual
800 GH narrow		2-piece 2 screws	factory sealed	n/a	760668	n/a (factory sealed)	MI 556500
800 GH 800 GN		2-piece 1 screw	factory sealed	n/a	760668	n/a (factory sealed)	MI 556500
800 GC	MAXCESS	1-piece 1 screw	not sealed fold-over	red 270013595	760668	Mark & cut 0.5" (12.7mm) outboard from the center of the end block fastener hole	MI 270013883
800 GX 800 GL 800 GE	MDLAND	1-piece 2 screws	not sealed not folded	blue 577982	760668	Mark & cut 0.14" (3.6mm) inboard from the center of the end block fastener holes	MI 651853
850 GS spiral element	O Company	1-piece 2 screws plastic tab	not sealed not folded install under end block tab	blue 577982	760668	Mark & cut 0.14" (3.6mm) inboard from the center of the end block fastener holes	MI 651853
860 GM reel spool		1-piece 4 screw	not sealed fold-over	white 577979	560345	Mark & cut 9/16" (14mm) longer than the outside edge of the element clamp pocket	MI 604918 1 K















