

# Adjustable Anvils



The AccuStrike™ Anvil allows press operators to adjust blade clearances on press with extreme precision. Controls enable the operator to adjust bearers independently or together for unparalleled control over die stike on various liner thicknesses.

## Features

- Easy to use dial controls with 0.001mm / 1.0 micron adjustment units
- Standard total adjustment travel to +0.001" (0.025mm) / -0.004" (0.10mm) - design can provide alternate travel range if desired
- Allows use of entire web width and center mounting of flexible dies
- Fully hardened wear surfaces
- Allows adjustment while the press is running or stopped

## Advantages

- Unit is maintenance and calibration free
- Outstanding versatility - interchanges simply and easily with standard press anvils, with no modification to the die station or press frame
- Drop-in installation for quick changeover between die stations
- Easy installation with minimal training required
- Increased die endurance and resulting life-cycle cost reductions

## WHY TRUST ROTOMETRICS?

We are an "exact fit" to your distinct needs. We know your presses, your tools and your materials. We back every tool we sell with the full support of our technical experts, offering advice and insights customized to address your specific needs. RotoMetrics is the right choice.

Contact a RotoMetrics representative today to discuss how you can benefit and profit with the highest quality printing and converting components offered.



The Adjustable Clearance Anvil allows press operators to adjust blade clearance on press with the turn of a single dial. Only RotoMetrics offers this unique feature which allows the operator to make unrestricted adjustments, versus incremental adjustments, to the depth of cut.

## Features

- Simple external dial control
- Fully hardened wear surfaces
- True concentricity (T.I.R) for maximum die cutting effectiveness

## Advantages

- Gives press operators a range of cutting depths within specified levels, with the turn of a single dial
- Allows on-press adjustment while press is running or stopped
- Interchanges simply and easily with standard press anvils on most machines
- Requires no modifications of existing die inventories
- Allows adjustment for liner caliper changes

